

## Crankshaft Trigger Wheel Installer - for JLR

Trigger wheel installer required to install the crankshaft position sensor ring on certain Land Rover engines and install trigger wheel to rear crankshaft on certain Jaguar models.



### Additional Information

- Land Rover applications: required to install the crankshaft position sensor ring on Discovery 3, Discovery 4 and Range Rover Sport when fitted with TDV6 engine.
- Jaguar applications: required to install the trigger wheel to the rear of the crankshaft on X200 S Type, X250 XF, X350 XJ and X351 XJ.
- Equivalent to OEM 303-1130.
- Overall diameter: 123.5mm.
- Specifically requested to repair sensor wheel dropping off or cracking.

<http://lasertools.co.uk/product/6831>



**LASER** 0831  
**Crankshaft Trigger Wheel Installer**  
Land Rover | Range Rover | Jaguar

**Land Rover Applications:** Required to install the crankshaft position sensor ring on Discovery 3/4, Range Rover Sport when fitted with TDV6 engine (3 Powertrain)

**Jaguar Applications:** Required to install the Trigger Wheel to the rear crankshaft on XJ200 S Type, XJ200 XP, XJ50 XJ and XJ51 XJ (300 Powertrain)

- Equivalent to OEM 300-1130
- Overall dimensions 125mm
- Specifically requested to repair sensor wheel dropping off or cracking

[www.lasertools.co.uk](http://www.lasertools.co.uk)